

Japanparts®



CAMSHAFT BEARINGS
BRONZINE ALBERO A
CAMME



www.japanparts.eu

CATALOGUE
FOR CARS AND
COMMERCIAL VEHICLES

CATALOGO
PER AUTOMOBILI E VEICOLI
COMMERCIALI

CAMSHAFT BEARINGS
BRONZINE ALBERO A CAMME



SH1070B

5-11610-602



SH1158A


11802-87380



DAIHATSU ROCKY Hard Top (F7, F8) 2.8 D
DAIHATSU ROCKY Soft Top (F7, F8) 2.8 D
DAIHATSU TAFT 2.5 D 4x4 (F50, F55)
DAIHATSU TAFT 2.8 D 4x4 (F60, F65)
DAIHATSU WILDCAT/ROCKY (F70) 2.8 D
DAIHATSU WILDCAT/ROCKY (F70) 2.8 TD

SH1161A


11802-54010



TOYOTA CRESSIDA Station Wagon (X6K, MX62) 2.2 D
TOYOTA CRESSIDA Tre volumi (_X6_) 2.2 D (LX60)
TOYOTA HIACE I Furgonato (RH1_, LH3_, RH3_, RH2_, LH2_, L 2.2 D (LH20-30)
TOYOTA HIACE II Furgonato (LH5_, YH7_, LH7_, LH6_, YH6_, 2.2 D

SH1166B

5-11611-010



ISUZU MIDI Autobus (94000, 98000) 2.0 TD (98000)
ISUZU MIDI Autobus (94000, 98000) 2.2 D (98000)
ISUZU MIDI Autobus (94000, 98000) 2.2 D 4WD (94000)
ISUZU MIDI Furgonato (98000N) 2.0 TD
ISUZU MIDI Furgonato (98000N) 2.2 D

SH1195B

13002-06J01



NISSAN PATROL GR I (Y60, GR) 4.2 Cat.

SH1401B

11802-56011



TOYOTA LAND CRUISER (_J4_) 3.0 D (BJ40_V, BJ43_)
TOYOTA LAND CRUISER (_J4_) 3.4 D (BJ42_V, BJ45_V, BJ46_)
TOYOTA LAND CRUISER (_J6_) 3.4 Diesel (BJ60_V)
TOYOTA LAND CRUISER Pick-up (_J4_) 3.4 D (BJ45_P)

SH1417B

11802-56020



TOYOTA DYNA Autobus (_U3_, _U2_) 3.4 D
TOYOTA DYNA Pianale piatto/Telaio 3.4 D
TOYOTA LAND CRUISER (PZJ7_, KZJ7_, HZJ7_, BJ7_, LJ7_, RJ7 3.4 D (BJ70_V, BJ73_)
TOYOTA LAND CRUISER (PZJ7_, KZJ7_, HZJ7_, BJ7_, LJ7_, RJ7 3.4 TD (BJ71_V)

SH1431A

11802-54020



TOYOTA DYNA 150 Pianale piatto/Telaio (LY_) 3.0 D
TOYOTA DYNA Pianale piatto/Telaio (KD_, LY_, TRY2_, KDY2_ 3.0 D4d
TOYOTA HIACE III Furgonato (YH7_, LH6_, LH7_, LH5_, YH5_, 2.4 Diesel
TOYOTA HIACE IV Autobus (LH1_) 2.4 TD (LXH12_, LXH22_)

SH1436B

11801-17010



TOYOTA LAND CRUISER (PZJ7_, KZJ7_, HZJ7_, BJ7_, LJ7_, RJ7 4.2 TD (HZJ7_V)
TOYOTA LAND CRUISER 80 (_J8_) 4.2 D (HZJ80_)
TOYOTA LAND CRUISER 80 (_J8_) 4.2 TD (HDJ80)

SH1605B

5-11610-002



ISUZU CAMPO (KB) 2.2 D (KBD27)
ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)
ISUZU TROOPER (UBS) 2.2 D 4x4
ISUZU TROOPER Fuoristrada aperto (UBS) 2.2 D (UBS52)
ISUZU TROOPER Fuoristrada aperto (UBS) 2.2 TD (UBS52)
OPEL CAMPO (TF_) 2.2 D (TFR52)

SH1622B

8-94168-556



ISUZU CAMPO (KB) 2.5 D (TFR54)
ISUZU CAMPO (KB) 2.5 D 4WD (KBD47)
ISUZU NPR 55 2.8 TD (4JB1)
ISUZU TROOPER (UB) 3.1 TD
ISUZU TROOPER (UBS) 2.8 TD (UBS55)
ISUZU TROOPER Fuoristrada aperto (UB) 3.1 TD
OPEL CAMPO (TF_) 2.5 D (TFR54)