

Japanparts®



STEERING RELAYS LEVE RINVIO STERZO



STEERING RELAYS

LEVE RINVIO STERZO



ID-100

OE: 48530-2S600



NISSAN PICK UP (D22) 2.5 D
4WD[02.1998-](Diesel)
NISSAN PICK UP (D22) 2.5 Di
4WD[03.2002-](Diesel)
NISSAN PICK UP (D22) 2.5 TD
4WD[05.1998-](Diesel)

100

ID-102

OE: 48530-B9500



ID-103

OE: 1954600



NISSAN TERRANO II (R20) 2.4 i 12V
4WD[02.1993-06.1996](Benzina)
NISSAN TERRANO II (R20) 2.7 TD
4WD[02.1993-01.2002](Diesel)
NISSAN TERRANO II (R20) 3.0 Di
4WD[05.2002-](Diesel)
NISSAN TERRANO II (R20) 3.0 DiTD
4WD[10.1997-06.2003](Diesel)

ID-107

OE: 48530-0F400



FORD MAVERICK (UDS, UNS) 2.4 i
(UDS)[09.1996-04.1998](Benzina)
FORD MAVERICK (UDS, UNS) 2.4
i[02.1993-08.1996](Benzina)
FORD MAVERICK (UDS, UNS) 2.4
i[09.1996-04.1998](Benzina)
FORD MAVERICK (UDS, UNS) 2.7
TD[02.1993-08.1996](Diesel)

ID-118

OE: 48530-01G00



NISSAN PICK UP (D21)
2.0[09.1985-07.1988](Benzina)
NISSAN PICK UP (D21)
2.0[09.1988-08.1991](Benzina)
NISSAN PICK UP (D21) 2.3
D[09.1985-08.1988](Diesel)
NISSAN PICK UP (D21) 2.4 i 12V
4WD[04.1992-02.1998](Benzina)

ID-119

OE: 48530-35G25



NISSAN TERRANO I (WD21) 2.4 i
4WD[10.1987-02.1993](Benzina)
NISSAN TERRANO I (WD21) 2.7 TD
4WD[02.1989-02.1996](Diesel)
NISSAN TERRANO I (WD21) 3.0 i
4WD[01.1990-12.1995](Benzina)

ID-120

OE: 48530-31G25



NISSAN PICK UP (D21) 2.4 i 12V
4WD[04.1992-02.1998](Benzina)
NISSAN PICK UP (D21) 2.4 i
4WD[03.1986-04.1992](Benzina)
NISSAN PICK UP (D21) 2.5 D
4WD[03.1986-08.1991](Diesel)
NISSAN PICK UP (D21) 2.5 D
4WD[03.1996-02.1998](Diesel)

ID-126

OE: 48530-18V00



NISSAN CEDRIC 2.0 (Y31)
CA20S[09.1987-](Benzina)
NISSAN CEDRIC 2.3 D (Y31) TD23
[09.1987-](Diesel)

ID-127

OE: 48530-G5101



NISSAN VANETTE Autobus (C22)
1.5[10.1986-12.1995](Benzina)
NISSAN VANETTE Autobus (C22) 2.0 D
(ULC22)[10.1986-12.1995](Diesel)
NISSAN VANETTE Autobus (C22) 2.4 i
(SLC22)[10.1986-12.1995](Benzina)
NISSAN VANETTE Furgonato (C22)
1.5[10.1986-12.1995](Benzina)

ID-128

OE: 48530-G5701



NISSAN VANETTE Autobus (C22)
1.5[10.1986-12.1995](Benzina)
NISSAN VANETTE Autobus (C22) 2.0 D
(ULC22)[10.1986-12.1995](Diesel)
NISSAN VANETTE Autobus (C22) 2.4 i
(SLC22)[10.1986-12.1995](Benzina)
NISSAN VANETTE Furgonato (C22)
1.5[10.1986-12.1995](Benzina)

ID-180

OE: 48530-G3701



NISSAN VANETTE Autobus (KC120)
1.5[01.1983-12.1987](Benzina)
NISSAN VANETTE Autobus (KC120) 2.0
D[01.1986-06.1987](Diesel)
NISSAN VANETTE Furgonato
1.5[03.1983-11.1986](Benzina)
NISSAN VANETTE Furgonato 2.0
D[11.1982-06.1987](Diesel)

180

ID-181

OE: 48530-15G25



NISSAN PICK UP (D21) 2.5
D[03.1996-02.1998](Diesel)
NISSAN PICK UP (D22) 2.5 Di[03.2002-]
(Diesel)
NISSAN PICK UP (D22) 2.5 D[02.1998-]
(Diesel)

181

STEERING RELAYS

LEVE RINVIO STERZO



ID-200


OE: 45490-39455



TOYOTA HILUX Fuoristrada chiuso (RZN1_, LN1_) 2.4 TD 4x4[08.1997-07.2001](Diesel)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 i 4WD[08.1997-](Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.5 D-4D 4WD[11.2001-](Diesel)

ID-201

OE: 45490-19125



TOYOTA COROLLA (KE) 1.2 (KE20, KE25)[10.1972-06.1977](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20, KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.2[09.1976-01.1980] (Benzina)

ID-203

OE: 45490-39466



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.5 D-4D[11.2001-] (Diesel)

ID-209

OE: 45490-19165



TOYOTA COROLLA (KE) 1.2 (KE20, KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.2[09.1976-01.1980] (Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.6[09.1976-01.1980] (Benzina)

ID-214

OE: 45490-39305



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 1.8 (YN85_, YN90_)[08.1988-07.1994](Benzi
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 D[03.1995-] (Diesel)

ID-215


OE: 45490-35140



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 1.8 (YN85_, YN90_)[08.1988-07.1994](Benzi
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.0[01.1984-12.1986](Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 D[01.1992-] (Diesel)

ID-226

OE: 45490-19215



TOYOTA COROLLA (KE) 1.2 (KE20, KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.2[09.1976-01.1980] (Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.6[09.1976-01.1980] (Benzina)

ID-229

OE: 45490-19225



TOYOTA COROLLA (KE) 1.2 (KE20, KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.2[09.1976-01.1980] (Benzina)
TOYOTA COROLLA 2 volumi /Coda spiovente (KE, TE) 1.6[09.1976-01.1980] (Benzina)

ID-230

OE: 45490-39445



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 TD 4WD[08.1998-01.2002](Diesel)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.5 D-4D 4WD[11.2001-](Diesel)

ID-234

OE: 45490-39365



TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 3.0 Turbo-D (KZN 130) [10.1993-03.1996](Diesel)
TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 3.0 V6 (VZN 130) [07.1990-11.1995](Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.2 4WD (YN106_, YN110_)[01.1987-12.1989]

ID-235

OE: 45490-29245



TOYOTA HIACE I Furgonato (RH1_, LH3_, RH3_, RH2_, LH2_, L 1.6 (RH20-30)[02.1977-03.1983](Benzina)
TOYOTA HIACE I Wagon (LH1_, RH1_, LH3_, RH3_, LH2_, RH2_) 1.6[01.1979-12.1984](Benzina)

ID-236

OE: 45490-29465



TOYOTA HIACE II Furgonato (LH5_, YH7_, LH7_, LH6_, YH6_, 1.8[03.1983-11.1989](Benzina)
TOYOTA HIACE II Furgonato (LH5_, YH7_, LH7_, LH6_, YH6_, 2.0[01.1984-11.1989](Benzina)
TOYOTA HIACE II Furgonato (LH5_, YH7_, LH7_, LH6_, YH6_, 2.2 D[03.1983-11.1989](Diesel)

STEERING RELAYS

LEVE RINVIO STERZO



ID-239

OE: 45490-35130



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 1.8 (YN85_, YN90_) [08.1988-07.1994] (Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.0 [01.1984-12.1986] (Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 D [01.1992-] (Diesel)

ID-240

OE: 45490-39315



TOYOTA HIACE III Furgonato (YH7_, LH6_, LH7_, LH5_, YH5_, 2.4 Diesel [02.1990-08.1995] (Diesel)
TOYOTA HIACE IV Autobus (LH1_) 2.4 D [07.1999-] (Diesel)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 1.8 (YN85_, YN90_) [08.1988-07.1994] (Benzina)

ID-243

OE: 45490-29475



TOYOTA DYNA Autobus (LY1_, _H8_) 2.4 D [08.1987-07.2001] (Diesel)
TOYOTA DYNA Pianale piatto/Telaio (LH8_) 2.4 D [08.1987-04.1995] (Diesel)

ID-244

OE: 45490-39255



TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 3.0 V6 (VZN 130) [07.1990-11.1995] (Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.0 [01.1984-12.1986] (Benzina)

ID-245

OE: 45490-39245



TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 2.4 (RN61) [08.1987-03.1996] (Benzina)
TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 2.7 i 4x4 [11.1995-03.1996] (Benzina)
TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 3.0 Turbo-D (KZN 130) [10.1993-03.1996] (Diesel)

ID-246

OE: 45490-29515



TOYOTA DYNA 100 Pianale piatto/Telaio (YH_) 1.8 [08.1985-04.1995] (Benzina)

ID-300

OE: 1454584



FORD RANGER (ER, EQ) 2.5 TDi [10.2005-] (Diesel)
FORD RANGER (ER, EQ) 2.9 D [06.1999-02.2002] (Diesel)
FORD RANGER (ER, EQ) 3.0 TDCi [10.2005-] (Diesel)
FORD RANGER (ES, ET) 2.5 TDCi 4x4 [04.2010-] (Diesel)

ID-310

OE: UB39-32-320



MAZDA B-SERIE (UF) 2.0 [01.1985-03.1996] (Benzina)
MAZDA B-SERIE (UF) 2.5 D [02.1996-06.1999] (Diesel)
MAZDA B-SERIE (UF) 2.6 4WD [01.1987-10.1990] (Benzina)
MAZDA B-SERIE (UN) 2.6 12V 4WD [06.1999-] (Benzina)

ID-313

OE: UB39-32-320B



MAZDA B-SERIE (UF) 2.2 D [01.1985-03.1996] (Diesel)
MAZDA B-SERIE (UF) 2.2 [08.1991-12.1996] (Benzina)

ID-316

OE: 4050675



FORD RANGER (ER, EQ) 2.5 D 4x4 [10.1999-04.2002] (Diesel)
FORD RANGER (ER, EQ) 2.5 D [10.1999-04.2002] (Diesel)
MAZDA B-SERIE (UF) 2.5 D [02.1996-06.1999] (Diesel)
MAZDA B-SERIE (UN) 2.5 D 4WD [06.1999-] (Diesel)

ID-317

OE: 1454584



FORD RANGER (ER, EQ) 2.9 D [06.1999-02.2002] (Diesel)
FORD RANGER (ER, EQ) 3.0 TDCi [10.2005-] (Diesel)
FORD RANGER (ES, ET) 2.5 TDCi 4x4 [04.2010-] (Diesel)
FORD RANGER (ES, ET) 3.0 TDCi 4x4 [04.2010-] (Diesel)

ID-318

OE: UB93-32-320



MAZDA B-SERIE (UF) 2.5 D 4WD [02.1996-06.1999] (Diesel)

STEERING RELAYS

LEVE RINVIO STERZO



ID-500

OE: MR296272



MITSUBISHI L 200 (K7_T, K6_T) 2.4 4x4 (K75T)[06.1996-](Benzina)
 MITSUBISHI L 200 (K7_T, K6_T) 2.5 TD 4WD (K74T)[09.2001-](Diesel)
 MITSUBISHI L 200 (K7_T, K6_T) 2.5 TD 4WD[08.2003-](Diesel)
 MITSUBISHI L 200 (K7_T, K6_T) 2.5 TD 4x4 (K74T)[06.1996-](Diesel)

ID-501

OE: MR296271



MITSUBISHI L 200 (K7_T, K6_T) 2.0 (K62T)[06.1996-](Benzina)
 MITSUBISHI L 200 (K7_T, K6_T) 2.5 D (K64T)[06.1996-](Diesel)
 MITSUBISHI L 200 (K7_T, K6_T) 2.5 TD[08.2001-11.2005](Diesel)

ID-503

OE: MB005820



MITSUBISHI GALANT I (A12_) 1.6[01.1977-08.1980](Benzina)
 MITSUBISHI GALANT I (A12_) 2.0 GLX[01.1977-08.1980](Benzina)
 MITSUBISHI GALANT I (A12_) 2.0[01.1979-08.1980](Benzina)
 MITSUBISHI GALANT I Station Wagon (A12_V) 1.6 GL (A121V)[01.1979-08.1980](Benzina)

ID-504

OE: MB122000



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 1.6 K11 (AG32)[03.1980-](Benzina)

ID-505

OE: MB166284



MITSUBISHI L 200 1.6[03.1980-08.1984](Benzina)
 MITSUBISHI L 200 1.6[09.1984-10.1986](Benzina)
 MITSUBISHI L 200 2.0 4WD[07.1981-09.1982](Benzina)
 MITSUBISHI L 200 2.0 4WD[10.1982-10.1986](Benzina)

ID-506

OE: MB122400



MITSUBISHI LANCER F II (A17_) 1.2 GLX (A171)[03.1983-01.1984](Benzina)
 MITSUBISHI LANCER F II (A17_) 1.4 GLX (A172)[03.1983-01.1984](Benzina)

ID-508

OE: MB241830



HYUNDAI GALLOPER II (JK-01) 2.5 TCi D[08.1998-](Diesel)
 HYUNDAI GALLOPER II (JK-01) 2.5 TD intercooler[08.1998-](Diesel)
 HYUNDAI GALLOPER II (JK-01) 2.5 TD[08.1998-](Diesel)
 HYUNDAI GALLOPER II (JK-01) 3.0 V6[08.1998-](Benzina)

ID-509

OE: MB241425



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 TD 4WD (K34T) [11.1992-08.1996](Diesel)

ID-510

OE: MB241423



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.0 4x4[11.1986-05.1992](Benzina)
 MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 D 4WD (K24T) [12.1987-05.1993](Diesel)
 MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 TD 4WD (K34T) [11.1992-08.1996](Diesel)

ID-511

OE: MB166429



MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 1.6 (L032P, L062P) [11.1984-02.1987](Benzina)
 MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 1.6 (L032P, L062P) [09.1981-10.1986](Benzina)
 MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 2.3 D (L038P)[04.1983-10.1986](Diesel)

ID-512

OE: MB315769



MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 1.6 (L032P, L062P) [11.1984-02.1987](Benzina)
 MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 1.6 (L032P, L062P) [09.1981-10.1986](Benzina)
 MITSUBISHI L 300 Autobus (LO3_P/G, LO_2P) 2.3 D (L038P)[04.1983-10.1986](Diesel)

ID-514

OE: MB527228



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.0 (K32T, K12T) [01.1987-12.1990](Benzina)
 MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 D (K14T)[11.1986-08.1996](Diesel)

STEERING RELAYS

LEVE RINVIO STERZO



ID-515

OE: MB831042



MITSUBISHI PAJERO CLASSIC (V2_W) 3.2 DI-D[05.2005-](Diesel)
MITSUBISHI PAJERO II (V3_W, V2_W, V4_W) 2.4[04.1991-04.2000](Benzina)
MITSUBISHI PAJERO II (V3_W, V2_W, V4_W) 2.5 TD (V24C, V24W) [12.1990-04.2000](Diesel)

ID-522

OE: MR-241030



MITSUBISHI L 200 (K7_T, K6_T) 2.5 D (K64T)[06.1996-](Diesel)

ID-523

OE: MR-296273



MITSUBISHI PAJERO CLASSIC (V2_W) 2.5 TD[07.2002-](Diesel)

ID-900

OE: 8-97106-663-0



ISUZU TFR/TFS Pick-up (TF_) 2.5 D[07.1994-08.1999](Diesel)
ISUZU TFR/TFS Pick-up (TF_) 2.8 D[10.1991-08.1999](Diesel)

ID-901

OE: 8-94231-4610



ISUZU CAMPO (KB) 2.2 (TFS) [01.1989-12.1990](Benzina)
OPEL FRONTERA A (5_MWL4) 2.2 i (54MWL4)[03.1995-10.1998](Benzina)
OPEL FRONTERA A (5_MWL4) 2.3 TD (5JMWL4)[03.1992-10.1998](Diesel)
OPEL FRONTERA A (5_MWL4) 2.4 i (53MWL4)[03.1992-10.1998](Benzina)

ID-904


OE: 8-94241-766-0



ISUZU TFR/TFS Pick-up (TF_) 2.5 D[07.1994-08.1999](Diesel)
ISUZU TFR/TFS Pick-up (TF_) 2.8 D[10.1991-08.1999](Diesel)

ID-997

OE: 8-97028-967-0



OPEL FRONTERA A (5_MWL4) 2.2 i (54MWL4)[03.1995-10.1998](Benzina)
OPEL FRONTERA A (5_MWL4) 2.3 TD (5JMWL4)[03.1992-10.1998](Diesel)
OPEL FRONTERA A (5_MWL4) 2.4 i (53MWL4)[03.1992-10.1998](Benzina)
OPEL FRONTERA A (5_MWL4) 2.5 TDS[09.1996-10.1998](Diesel)

ID-H50

OE: 56820-H1002



HYUNDAI TERRACAN (HP) 2.5 TD[12.2001-](Diesel)
HYUNDAI TERRACAN (HP) 2.9 CRD[11.2003-](Diesel)
HYUNDAI TERRACAN (HP) 3.5 i V8 4WD[12.2001-](Benzina)

ID-H54

OE: 56940-44000



HYUNDAI H100 Autobus (P) 2.5 D[07.1993-12.1994](Diesel)
HYUNDAI H100 Autobus (P) 2.5 D[12.1994-03.2000](Diesel)
HYUNDAI H100 Furgonato 2.5 D[07.1993-12.1994](Diesel)

ID-K00

OE: 0K011-32-320A



KIA RETONA (CE) 2.0 16V[05.2000-](Benzina)
KIA RETONA (CE) 2.0 TD[06.1999-](Diesel)
KIA SPORTAGE (K00) 2.0 4WD[10.2000-08.2003](Benzina)
KIA SPORTAGE (K00) 2.0 i 16V 4WD[04.1994-08.2003](Benzina)

PI-100

OE: 48502-3S525



NISSAN NAVARA (D22) 2.5 D 4x4[11.2001-](Diesel)
NISSAN NAVARA Pianale piatto/Telaio (D22) 2.5 Di[01.2008-](Diesel)
NISSAN PICK UP (D22) 2.4 i 4WD[02.1998-](Benzina)
NISSAN PICK UP (D22) 2.5 D 4WD[02.1998-](Diesel)

PI-200

OE: 45401-39145



TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.4 D[08.1988-](Diesel)

STEERING RELAYS

LEVE RINVIO STERZO



PI-202

OE: 45401-19066



TOYOTA CARINA (TA1_)
1.6[10.1975-03.1978](Benzina)
TOYOTA CELICA (RA2_, TA2_)
2.0[10.1975-07.1977](Benzina)
TOYOTA CORONA (RT1_) 1.8 (TT1)
[06.1979-01.1981](Benzina)
TOYOTA CORONA (RT1_) 2.0 Mark II
(RX12)[12.1975-10.1977](Benzina)

PI-203

OE: 45401-19045



TOYOTA COROLLA (KE) 1.2 (KE20,
KE25)[10.1972-06.1977](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda
spiovente (KE, TE) 1.2[09.1976-01.1980]
(Benzina)

PI-210

OE: 45401-19095



TOYOTA COROLLA (KE) 1.2 (KE20,
KE25)[10.1972-06.1977](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda
spiovente (KE, TE) 1.2[09.1976-01.1980]
(Benzina)

PI-211

OE: 45411-35220



TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.4 D[08.1988-]
(Diesel)

PI-212

OE: 45401-19055



TOYOTA COROLLA (KE) 1.2 (KE20,
KE25)[10.1972-06.1977](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda
spiovente (KE, TE) 1.2[09.1976-01.1980]
(Benzina)

PI-216

OE: 45401-19175



TOYOTA COROLLA (_E7_) 1.3 (KE70)
[02.1982-06.1983](Benzina)
TOYOTA COROLLA (_E7_) 1.3 (KE70)
[09.1979-06.1983](Benzina)
TOYOTA COROLLA (_E7_) 1.6 (TE71)
[10.1982-09.1983](Benzina)
TOYOTA COROLLA (_E7_) 1.8 D (CE70)
[01.1983-09.1983](Diesel)

PI-220

OE: 45401-19105



TOYOTA COROLLA (KE) 1.2 (KE20,
KE25)[10.1972-06.1977](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25, KE30)[08.1974-12.1980](Benzina)
TOYOTA COROLLA 2 volumi /Coda
spiovente (KE, TE) 1.2[09.1976-01.1980]
(Benzina)

PI-224

OE: 45401-29145



TOYOTA CRESSIDA Station Wagon
(RX3_) 2.0 (RX35)[12.1977-03.1981]
(Benzina)
TOYOTA CRESSIDA Station Wagon (X6K,
MX62) 2.0[02.1981-03.1985](Benzina)
TOYOTA CRESSIDA Station Wagon (X6K,
MX62) 2.2 D[06.1981-03.1985](Diesel)
TOYOTA CRESSIDA Tre volumi (RX3_)
2.0 (RX30)[07.1977-07.1981](Benzina)

PI-229

OE: 4540135270



TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.4 i
4WD[08.1997-](Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.4 TD
4WD[08.1998-01.2002](Diesel)

PI-234

OE: 45401-35180



TOYOTA HILUX II Pianale piatto/Telaio
(LN6_, LN5_, YN6_, 2.4 D
AWD[01.1984-08.1988](Diesel)
TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 1.6
[08.1978-08.1988](Benzina)
TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 1.8 (YN85_,
YN90_) [08.1988-07.1994](Benzi

PI-235

OE: 45401-35190



TOYOTA 4 RUNNER (RN10_, VZN13_,
VZN10_, RN13_) 2.4 (RN61)
[08.1987-03.1996](Benzina)
TOYOTA 4 RUNNER (RN10_, VZN13_,
VZN10_, RN13_) 2.7 i
4x4[11.1995-03.1996](Benzina)
TOYOTA 4 RUNNER (RN10_, VZN13_,
VZN10_, RN13_) 3.0 Turbo-D (KZN 130)
[10.1993-03.1996](Diesel)

PI-236

OE: 45401-35240



TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.2 4WD
(YN106_, YN110_) [01.1987-12.1989]
TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.4 D
4WD[01.1994-](Diesel)
TOYOTA HILUX II Pick-up (RN6_, RN5_,
LN6_, YN6_, YN5_, LN 2.4 D
4WD[08.1988-](Diesel)

STEERING RELAYS

LEVE RINVIO STERZO



PI-237

OE: 45401-35260



TOYOTA HILUX II Pianale piatto/Telaio (LN6_, LN5_, YN6_, 3.0 D Trazione integrale 4x4[08.1997-08.20 TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.5 D-4D 4WD[11.2001-])(Diesel) TOYOTA HILUX II Pick-up (RN6_, RN5_, LN6_, YN6_, YN5_, LN 2.7 4 ruote motrici[11.1997-04.2005])(Benz

PI-300

OE: UR56-32-220



FORD RANGER (ER, EQ) 2.5 TDdi[10.2005-])(Diesel) MAZDA BT-50 (CD, UN) 2.5 CD 4WD[12.2006-])(Diesel)

PI-303

OE: UA01-32-220



MAZDA B-SERIE (UD) 1.8[10.1981-08.1985])(Benzina)

PI-304

OE: E17Z-3590A



MAZDA B-SERIE (PE) 1.6[02.1977-09.1978])(Benzina) MAZDA B-SERIE (PE) 1.8[02.1977-01.1982])(Benzina) MAZDA B-SERIE (UD) 1.8[10.1981-08.1985])(Benzina) MAZDA B-SERIE (UD) 2.0[01.1983-12.1984])(Benzina)

PI-305

OE: UH7132220



FORD RANGER (ER, EQ) 2.5 D[10.1999-04.2002])(Diesel) FORD RANGER (ER, EQ) 2.5 TD[04.2002-])(Diesel) FORD RANGER (ER, EQ) 2.9 D[06.1999-02.2002])(Diesel) MAZDA B-SERIE (UN) 2.5 D[06.1999-])(Diesel)

PI-306

OE: 0370-32-220



MAZDA RX 7 I (SA) Wankel[01.1981-03.1984])(Benzina) MAZDA RX 7 I (SA) Wankel[03.1984-03.1986])(Benzina) MAZDA RX 7 I (SA) Wankel[05.1979-05.1981])(Benzina)

PI-314

OE: UB39-32-220B



MAZDA B-SERIE (UF) 2.0[01.1985-03.1996])(Benzina) MAZDA B-SERIE (UF) 2.0[01.1985-12.1991])(Benzina) MAZDA B-SERIE (UF) 2.2 D[01.1985-03.1996])(Diesel) MAZDA B-SERIE (UF) 2.2[08.1991-12.1996])(Benzina)

PI-500

OE: MR296508



MAZDA B-SERIE (UF) 2.2 D[01.1985-03.1996])(Diesel) MAZDA B-SERIE (UF) 2.2[08.1991-12.1996])(Benzina)

PI-502

OE: MB076010



MITSUBISHI GALANT I (A12_) 1.6[01.1977-08.1980])(Benzina)

PI-503

OE: MB076009



MITSUBISHI GALANT I (A12_) 1.6[01.1977-08.1980])(Benzina) MITSUBISHI GALANT I (A12_) 2.0 GLX[01.1977-08.1980])(Benzina) MITSUBISHI GALANT I (A12_) 2.0[01.1979-08.1980])(Benzina) MITSUBISHI GALANT I Station Wagon (A12_V) 1.6 GL (A121V)[01.1979-08.1980])(Benzina)

PI-504

OE: MB122396



MITSUBISHI LANCER F II (A17_) 1.2 GLX (A171)[03.1983-01.1984])(Benzina) MITSUBISHI LANCER F II (A17_) 1.4 GLX (A172)[03.1983-01.1984])(Benzina) MITSUBISHI LANCER F II (A17_) 1.4 Turbo[03.1983-01.1984])(Benzina)

PI-508

OE: MB241168



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 D 4WD (K24T) [12.1987-05.1993])(Diesel) MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 TD 4WD (K34T) [11.1992-08.1996])(Diesel) MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.6 4WD (K33T)[11.1989-05.1995])(Benzina)

STEERING RELAYS

LEVE RINVIO STERZO



PI-509

OE: MB166281



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 D (K14T)[11.1986-08.1996] (Diesel)

PI-510

OE: MB241973



MITSUBISHI PAJERO I (L04_G, L14_G) 2.5 TD (L044G, L049G)[01.1990-12.1991] (Diesel)
MITSUBISHI PAJERO I (L04_G, L14_G) 2.5 TD (L044G, L049G)[11.1989-11.1990] (Diesel)
MITSUBISHI PAJERO I (L04_G, L14_G) 2.5 TD 4x4[10.1986-05.1991](Diesel)

PI-511

OE: MB241884



MITSUBISHI PAJERO I Canvas Top (L04_G) 2.3 TD (L043G, L048G) [12.1982-04.1986](Diesel)

PI-512

OE: MB831040



MITSUBISHI PAJERO CLASSIC (V2_W) 2.5 TD[07.2002-](Diesel)
MITSUBISHI PAJERO CLASSIC (V2_W) 3.2 DI-D[05.2005-](Diesel)
MITSUBISHI PAJERO II (V3_W, V2_W, V4_W) 2.4[04.1991-04.2000](Benzina)
MITSUBISHI PAJERO II (V3_W, V2_W, V4_W) 2.5 TD (V24C, V24W) [12.1990-04.2000](Diesel)

PI-513

OE: MR241029



MITSUBISHI L 200 (K7_T, K6_T) 2.0 (K62T)[06.1996-](Benzina)
MITSUBISHI L 200 (K7_T, K6_T) 2.5 D (K64T)[06.1996-](Diesel)

PI-514

OE: MB598489



MITSUBISHI PAJERO I (L04_G, L14_G) 2.5 TD (L044G, L049G)[01.1990-12.1991] (Diesel)
MITSUBISHI PAJERO I (L04_G, L14_G) 2.5 TD (L044G, L049G)[11.1989-11.1990] (Diesel)
MITSUBISHI PAJERO I (L04_G, L14_G) 3.0 V6 (L141G, L146G)[11.1988-11.1990] (Benzina)

PI-515

OE: MB527227



MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 D 4WD (K24T) [12.1987-05.1993](Diesel)
MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.5 TD 4WD (K34T) [11.1992-08.1996](Diesel)
MITSUBISHI L 200 (K3_T, K2_T, K1_T, K0_T) 2.6 4WD (K33T)[11.1989-05.1995] (Benzina)

PI-521

OE: MB166425



MITSUBISHI L 300 Furgonato (L03_P) 1.6 (L032P, L062P)[05.1980-10.1986] (Benzina)

PI-523

OE: MB166423



MITSUBISHI L 300 Autobus (LO3_P/G, L0_2P) 1.6 (L032P, L062P) [09.1981-10.1986](Benzina)
MITSUBISHI L 300 Furgonato (L03_P) 1.6 (L032P, L062P)[05.1980-10.1986] (Benzina)

PI-599

OE: MB166424



MITSUBISHI L 300 Autobus (LO3_P/G, L0_2P) 1.6 (L032P, L062P) [09.1981-10.1986](Benzina)
MITSUBISHI L 300 Furgonato (L03_P) 1.6 (L032P, L062P)[05.1980-10.1986] (Benzina)

PI-600

OE: 45408-87-601-000



DAIHATSU FERROZA Hard Top (F300) 1.6 16V[10.1988-](Benzina)
DAIHATSU FERROZA Hard Top (F300) 1.6 i 16V[10.1988-](Benzina)
DAIHATSU FERROZA Soft Top (F300) 1.6 16V[10.1988-](Benzina)
DAIHATSU FERROZA Soft Top (F300) 1.6 i 16V[10.1988-](Benzina)

PI-601

OE: 45408-87602



DAIHATSU ROCKY Hard Top (F7, F8) 2.0[02.1985-04.1993](Benzina)
DAIHATSU ROCKY Hard Top (F7, F8) 2.8 D[02.1985-](Diesel)
DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[12.1987-04.1993](Diesel)
DAIHATSU ROCKY Soft Top (F7, F8) 2.0[02.1985-04.1993](Benzina)

STEERING RELAYS

LEVE RINVIO STERZO



PI-601E

OE: 45408-87602



DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[05.1993-](Diesel)
DAIHATSU ROCKY Soft Top (F7, F8) 2.8 D[02.1985-](Diesel)

PI-800

OE: 48721-60A00



SUZUKI SIDEKICK 1.6 i 16V 4x4 (ET - TA02)[07.1990-03.1998](Benzina)
SUZUKI VITARA (ET, TA) 1.6 (ET) [07.1988-12.1991](Benzina)
SUZUKI VITARA (ET, TA) 1.6 16V (ET) [07.1990-03.1998](Benzina)
SUZUKI VITARA (ET, TA) 1.9 D (ET) [01.1995-03.1998](Diesel)

PI-900

OE: 8-97028-970-0



ISUZU D-MAX (8DH) 2.5 D[10.2002-](Diesel)
ISUZU D-MAX (8DH) 3.0 DiTD[10.2002-](Diesel)
OPEL CAMPO (TF_) 2.5 TD (TFR54) [07.1994-](Diesel)
OPEL CAMPO (TF_) 2.5 TD 4x4 (TFS54) [07.1994-](Diesel)

PI-H00

OE: 57720-M1000



HYUNDAI GALLOPER II (JK-01) 2.5 TCi D[08.1998-](Diesel)
HYUNDAI GALLOPER II (JK-01) 2.5 TD intercooler[08.1998-](Diesel)
HYUNDAI GALLOPER II (JK-01) 3.0 V6[08.1998-](Benzina)
MITSUBISHI GALLOPER (JK-01) 2.5 TD[02.1999-](Diesel)

PI-H01

OE: 57730-H1100



HYUNDAI TERRACAN (HP) 2.5 TD[12.2001-](Diesel)
HYUNDAI TERRACAN (HP) 2.9 CRDi[11.2001-07.2003](Diesel)
HYUNDAI TERRACAN (HP) 2.9 CRDi[11.2003-](Diesel)
HYUNDAI TERRACAN (HP) 2.9 CRDi[12.2001-](Diesel)